

OUTPUT VOLTAGE ALARM CIRCUIT



DESIGN NOTE 007

Ericsson Power Modules

ericsson.
com

OUTPUT VOLTAGE ALARM CIRCUIT

This design note shows one example on how to detect output voltage and provide a status signal by using LED diodes.

In the circuit below, choose R1 to set a current that provides a stable reference voltage for IC1. Voltage divider R2, R3 will set the trip level for IC1, which compares the reference voltage with the voltage for the combination of R2, R3. During start up the red LED will light up momentarily until the Vtrip level is passed.

$$V_{trip} = V_{ref} \times \frac{(R2 + R3)}{R3}$$

R6 sets the current through the diode of the opto-coupler. 1mA is usually enough but it will depend on the current transfer ratio of the optocoupler. The current needed through the optocoupler transistor is calculated by the input supply voltage divided by the sum of R7 and R8.

R9 and R13 set the current through the LED diodes.

SEE DESIGN EXAMPLE ON THE
FOLLOWING PAGE:

Design example:
5V output, 36–72V input

Component values:


R1, R2, R3, R6, R9, R13	4.7 k Ω
R8, R12	10 k Ω
R7, R10	68 k Ω
R11	100 k Ω
D1	1N4148
IC1A	LM 224 or 324
Q1, Q2	BC 639 or similar

Reference voltage:

2.5V

Optocoupler:

Toshiba TLP 121 or similar



Ericsson is shaping the future of Mobile and Broadband Internet communications through its continuous technology leadership.

Providing innovative solutions in more than 140 countries, Ericsson is helping to create the most powerful communication companies in the world.

Formed in the late seventies, Ericsson Power Modules is a division of Ericsson AB that primarily designs and manufactures isolated DC/DC converters and non-isolated voltage regulators such as point-of-load units ranging in output power from 1 W to 700 W. The products are aimed at (but not limited to) the new generation of ICT (information and communication technology) equipment where systems' architects are designing boards for optimized control and reduced power consumption.

Power Modules – Americas

Telephone: +1-972-583-5254
+1-972-583-6910

Power Modules – Asia/Pacific

Telephone: +852-2590-2453

Ericsson AB, Power Modules

SE-164 80 Stockholm, Sweden
Telephone +46 10 716 9620

The content of this document is subject to revision without notice due to continued progress in methodology, design and manufacturing. Ericsson shall have no liability for any error or damage of any kind resulting from the use of this document